



Locus, Incorporated

5540 Research Park Drive, Fitchburg Center – Madison, WI 53711 USA
608.270.0500 fax: 608.270.5257 locus@locusinc.com

SatMate and CsSync 1000/1020/1030 Software Installation Instructions

1. Unzip the file into a new directory. There should be a total of 10 files. *Caution – Only install SatMate 1000 software into a SatMate 1000, SatMate 1020 software into a SatMate 1020 and SatMate 1030 software into a SatMate 1030.*
2. Connect the SatMate to the COM 1 or COM 2 port of the PC and set the baud rate to 9600. Note – If your computer does not have a COM 2 port then you will need to edit the three .cfg files and change “-cc2” to “-cc1”.
3. Close ALL programs in Windows.
4. Open a DOS window and make it full screen (The button with the 4 arrows pointing outward will do this). Note: You should not see a border. The screen background should be black.
5. Go to the directory where the new files were placed.
6. Run the appropriate batch file depending on your PC's operating system. Use "Win16bit.bat" for anything earlier than Windows 95. Use "Win95a.bat" for the original Windows 95 version. Use "Win95-XP.bat" for anything newer than the original Windows 95.
7. Wait until you see an update frame. This will be the same info you see when operating the receiver.
8. If the receiver is attached to COM 1 proceed to step 9. If the receiver is attached to COM 2 press the “F2” (function key 2) button.
9. Press “Alt-U” (press the “U” key while holding down the “Alt” key). This will upload the new software. **NOTE:** While the new software is loading and the words "erasing" and/or "programming" are displayed, you *MUST NOT* turn the receiver power off. Doing so will leave the receiver in an unrecoverable state and it will need to be sent back to Locus for reprogramming.
10. Once the upload is finished you will see a message informing you of this. At this point the reprogramming is complete and you may close the DOS window.